



Hand-Held Scarifiers



Needleguns



Walk-Behind Scarifiers



Impact Tools



Sanders



Specialty Tools



Industrial Vacuums



Mixer

Pneumatic

Part # 400.021



1. Tighten power tool chuck onto drive shaft of mixer.
2. The mixer **MUST BE FULLY IMMERS**ED in the material to be mixed before turning on the power tool, and **MUST BE KEPT FULLY IMMERS**ED WHILE IN MOTION.
3. Hold power tool and mixer firmly. The container in which mixing is to be done should be secure so that it will not be thrown, spilling contents.
4. **PREPARED, PACKAGED STOCK-TYPE** materials, such as powders or pigments used in formulation can product a sticky mass on the bottom of the container which must be loosened and dispersed. **SUBMERGE** mixer to within approximately 1" of bottom of container. Turn on power and move mixer around bottom area until settled material has been brought into the mixture. Slowly move the mixer up and down and around in the material until contents are thoroughly mixed into a smooth, uniform body.
5. Clean mixer after each use. Simply immerse in compatible solvent or water and run until clean. When cleaning solution is flammable, be sure to remove mixer from the power tool. Food service operators can put smaller mixers in their dishwashers.
6. Never run mixer outside of the mixing or cleaning container.
7. DO NOT exceed maximum speed of 800 rpm.

DESCO Mfg. Co., Inc.

23031 Arroyo Vista • Rancho Santa Margarita, CA 92688
949.858.7400 • 949.858.9141 fax • 800.337.2648 toll free
www.descomfg.com • info@descomfg.com